

This is to help you get to know the main switches & controls in the Mazda 2

WINDSCREEN WIPERS

UP ONCE FOR SINGLE WIPE
DOWN ONCE FOR INTERMITTENT WIPE
ONCE MORE FOR NORMAL SPEED
ONCE MORE FOR FAST SPEED
PULL TOWARDS YOU TO WASH FRONT SCREEN
REAR WASHER/WIPER OPERATED BY TWISTING END

HAZARD WARNING LIGHTS

DIRECTION INDICATORS & LIGHTS (Front & Rear Lights & Fog Lights)

ENGINE START BUTTON HORN

HEATING & VENTILATION

TEMPERATURE FAN SPEED AIR DIRECTION

AIR CON REAR DEMIST



REV COUNTER

SPEEDOMETER

FUEL GAUGE